

Solutions for Your TOUGHEST
MIXING Applications in

FOOD



Preparation of Petfood
Gravies and Jellies

Preparation of Petfood Gravies and Jellies

Most tinned dog and cat food is based on a slurry of meat or meat derivatives and cereals. Some products also contain fish. The slurry, which may be extruded, rolled or pressed into chunks, is then mixed with a “gravy” or a higher viscosity jelly, typically a mixture of starches or gums such as xanthan, guar, carageenan, locust bean, etc. in water. Other gravy ingredients could include coloring, flavor enhancers, vitamins, and minerals.

The Process

A typical gravy would be manufactured as follows:

- The processing vessel is charged with water. This may be cold or heated to 140 - 175°F (60 - 80°C) depending on a number of processing factors.
- The agitator is started; the powdered ingredients are then added.
- As a mixture of gums and thickeners is often used these may be premixed with the other powdered ingredients. This aids incorporation of lighter powders and can help prevent formation of agglomerates.
- The powder mix is gradually added into the vortex created by the agitator.
- Mixing continues after the powders have been dispersed, to allow hydration to be completed and the desired viscosity to be obtained.


The Problem

Dispersion of gums and thickeners using conventional agitators can give rise to several problems:

- Potential full yield is difficult to obtain using traditional methods.
- Many formulations contain unnecessarily high levels of some raw materials to compensate for poor yield.
- Agglomerates can easily form. Agitators do not produce sufficient shear to rapidly break these down.
- Some gums and thickeners are not “activated” unless particle size is sufficiently reduced.
- A degree of shear is sometimes required to activate some products and fully hydrate them.
- Once viscosity increase has started, agitation of the solution and therefore powder dispersion becomes increasingly inefficient.
- Long mixing times are required to complete dispersion/hydration.
- Undissolved gum or thickening agent can gradually hydrate during storage or subsequent processing, leading to undesired changes in product viscosity.

The Solution

A Silverson High Shear mixer can produce an agglomerate-free gravy in a fraction of the time taken by conventional methods. This can be achieved using a Batch mixer immersed in the vessel or an In-Line mixer in a recirculation system (see overleaf). For large volumes of powders the Silverson Flashmix is most suitable. Operation is as follows:



The self-pumping Flashmix draws water from the vessel into the high shear rotor/stator workhead then recirculates it back into the top of the vessel. The powder is fed into the specially designed hopper. Once the water is recirculating the powder feed valve can be opened. The powder is drawn into the liquid stream and passes immediately to the inlet of the In-Line mixer. The liquid and solids are subjected to intense high shear in the workhead of the In-Line mixer before being pumped back into the vessel. A short recirculation period completes the hydration process.


The Advantages

- The greatly improved yield can allow products to be formulated with reduced gum/thickener content, cutting raw material costs.
- Agglomerate-free mix.
- Operator error is effectively eliminated.
- Rapid mixing times.
- Consistent product quality and repeatability.
- Solution can be achieved at ambient temperatures, depending on concentration and viscosity of end product.

The batch size, formulation, type of ingredients and the viscosity of the end product dictates which Silverson model is best suited to processing requirements - see overleaf.


Silverson Ultramix

- Excellent in-tank movement
- Capable of rapidly incorporating large volumes of powders
- Ultra Sanitary CIP design
- Ideal for higher viscosity mixes
- Low maintenance




High Shear Batch Mixers

- Suitable for batches of up to 300 US gallons
- Can be used on mobile floor stands
- Can easily be moved from vessel to vessel




High Shear In-Line Mixers

- Ideal for larger batches
- Easily retrofitted to existing plant
- Must be used in conjunction with an efficient in-tank agitator to wet out powder
- Aeration free
- Self-pumping
- Can be used to discharge vessel
- Ultra Sanitary models available
- High Viscosity models available




High Shear Bottom Entry Mixers

- No immersed shaft- reduces cleaning requirements



Silverson Flashmix

- Ideal for larger batches
- Capable of rapidly incorporating large volumes of powders
- Minimized aeration
- Minimized cleaning requirements
- Suitable for higher viscosity mixes
- Suitable for operation at higher temperatures
- Minimum operator input required



For more information click here to go to www.silverson.com

Silverson Machines, Inc. 355 Chestnut Street, East Longmeadow, MA 01028

Ph: (413) 525-4825 sales@silverson.com

Information contained in this report is believed to be correct and is included as a guide only. No warranty is expressed or implied as to fitness for use or freedom from patents. Silverson Machines reserve the right to change product specification without notice.

Issue No. 32FA4